

Section 11: Machine Language Linkage	97
CALL	97
SCALL	100
Section 12: ROMSquared Features	103
Working Space	103
MOVE	103
EXEC	104
FIRST and LAST	105
Default Initialization Options	106
Section 13: Errors	107
TRAP and UNTRAP	107
Error Types	108
Section 14: Editing Commands	111
AUTO	111
DELETE	112
EDIT	112
RENUM	114
Section 15: CP/M Sequential Disk Commands	116
Filenames	116
OPEN	116
CLOSE	117
PRINT	117
MARGIN	118
INPUT	118
LINPUT	119
EOF	119
DIR	120
SCRATCH	120
CLEAR	121
II. VERSION DIFFERENCES	122
Section 1: CP/M Version	122
Section 2: ISIS-II Version	122
Section 3: Custom I/O Version	123
Device Driver Locations	124
Sample I/O Patch	125
SAVED Program Format	127
Saving and Loading Under Operating Systems	129
Section 4: INTEL SBC Series Versions.	130
Section 5: AMD 9511 Floating Point Version.	131
Section 6: XYBASIC Compiler	132
Compiler Operation	132
Object File Execution	133
Section 7: XYBASIC Runtime Module	134